

# Install Checklist

## Brick, Stone and Wood

GenStone goes from the box to any flat wall in minutes with basic hand tools and no special skills. Simply measure, cut and attach.

### ✓ Support and Guidance

We're there for you every step of the way!

Install Guide • Install Videos • 1-855-397-1294 • [info@genstone.com](mailto:info@genstone.com)

### ○ Cover Up and Clean Up

Safety first! Be ready for a sawdust like dust from your cuts.

Safety Glasses • Breathing Protection • Gloves • Vacuum

### ○ Measuring for Cuts

Measurements are made by dry fitting panels or measuring voids.

Tape Measure • Framing Square • Marker

### ○ Cutting Panels, Ledgers and Trim

Choose from the cutting tools you're most comfortable with, all will work!

Hand Saw • Miter Box • Chop Saw • Table Saw • Utility Knife

### ○ Keeping it Level

A large and small level is suggested, don't use the floor or ceiling!

Large Level • Small Level • Laser Level • Chalk Line

### ○ Attaching Panels

GenStone can be installed over any flat surface

One White Caulking Every 100 SQFT • One Adhesive Every 100 SQFT

Wood	Deck Screws	PL Premium Adhesive	GenStone White Caulking
Concrete	Tapcon Screws	PL Premium Adhesive	GenStone White Caulking
Stucco	Tapcon Screws	PL Premium Adhesive	GenStone White Caulking
Brick	Tapcon Screws	PL Premium Adhesive	GenStone White Caulking
Drywall	Drywall Screws	GenStone White Caulking	

### ○ Finish Like a Pro

The details make a difference!

Paint Kit • GenStone eXact Color Caulking • Latex or Similar Gloves • Sponge

**GenStone**<sup>®</sup>

EMAIL  
[info@genstone.com](mailto:info@genstone.com)

CALL  
1-855-397-1294

ONLINE  
[www.genstone.com](http://www.genstone.com)